

CALDERA RIP 14.0

Caldera RIP V14.0 Update Changelog

Caldera RIP V14.0 Update Changelog

Build 201117

1

1

Caldera RIP V14

Caldera® and all Caldera products mentioned in this publication are trademarks of Caldera.

A build update contains all fixes from previous updates.

Build 201117

New CalderaCare features

- **Cut:** Increased range for Contour offsets (from [-10 mm,+10 mm] to [-100 mm,+100 mm]) (#2274).¹

New features

- **Cut:** Add auto-rotate jobs for Teckcel Opticam (#2226).
- **Print Standard Verifier :** Support of FOGRA PSD 2018 (#2357). Media relative grey values have been modified in accordance to last FOGRA Print Standard Digital 2018. Absolute max check is now based on 95% percentile.

Bug fixing

- **Fileman:** Fix a freeze with Fileman with certain PDF files (#2250).
- **Nest:** Fix wrong file name when nesting tiles with bleeding in Nest-O-Matik(#1287).
- **Inksaving:** Version 3 does not require CalderaCare anymore for Caldera RIP V14 (#2276).
- **Spooler:** Fix second desktop was not available for Debian 10 (#1888).
- **Compose:** Fix ExtraMarks not printed when generating them in Compose (#2197).
- **Bleed:** Fix rectangular bleed, excessive white on the sides of the print (#2041 and #2346).

Spectrophotometers

- **X-Rite i1 iO3:** When finishing to read a page for multi-page targets, the arm is moved at the top-left location of the table and unlocked (#2245).
- **X-Rite i1 iO3:** Fix a crash in EasyMedia when the device was not able to read a target (#2143).
- **i1 Pro 3:** (Debian9) Fix an error when reopening the device after a scan (#1668).

Cutters

- **FC9000:** Support of horizontal marks without paneling (#2326).
- **Summa GoProduce:** Fix Barcode 39 (#2298).
- **Graphtec:** Prevent the user from clicking the button when connection is not ready (#2306).

¹Limitations: With complicated contours, big values can generate unusable contours, you can check in the preview.