



# Spectro pad<sup>®</sup> Series 2

Reflection spectrophotometer  
for digital imaging market

## Operating Manual

edition 08/14 for Firmware version 6.00 or newer





# Barbieri Spectropad

## 1. CONTENTS

1. INTRODUCTION.....	4
1.1 WHAT YOU CAN DO WITH THIS INSTRUMENT .....	5
1.2 UNPACKING THE INSTRUMENT .....	6
1.3 COMPONENTS .....	7
2. PUTTING INTO OPERATION.....	8
2.1 BATTERY CHARGING .....	8
2.2 USB CONNECTION.....	9
2.1 PRODUCT REGISTRATION .....	12
3. USING THE INSTRUMENT .....	13
3.1 STATUSBAR .....	13
3.2 BEGINNER-MODE.....	13
3.3 TOUCH PANEL .....	14
3.4 SHOWING INSTRUMENT INFORMATION .....	14
3.5 CALIBRATION .....	15
3.6 MEASURING REFLECTIVE SAMPLES .....	16
3.7 MEASURE THIN REFLECTIVE SAMPLES .....	18
4. CHART MEASURING MODE .....	19
5. DOC MEASURING MODE.....	22
MEASURING A REFERENCE STRIP .....	23
MEASURING A CONTROL STRIP .....	24
6. SPOT MEASURING MODE .....	26
6.1 IMAGE QUALITY MODE .....	29
6.2 LINE MEASURING MODE .....	30
7. SETTINGS.....	31
7.1 WIFI INTERFACE CONFIGURATION.....	31
7.2 BEGINNER MODE CONFIGURATION.....	33
8. INSTRUMENT MAINTENANCE .....	34
8.1 CHANGING THE REFERENCE WHITE.....	34
8.2 PACKING THE INSTRUMENT FOR TRANSPORT.....	34
9. SPECIFICATIONS .....	35

# Barbieri Spectropad

## 1. INTRODUCTION

We congratulate you on your choice!

We from BARBIERI electronic are proud of presenting to you the spectrophotometer Spectropad. This instrument features the latest technology in precise optics, state-of-the-art electronics and software functionality. It is especially created for use in digital imaging market and in particular for industrial printing applications.

May we suggest you read the operating manual first for fully enjoying the capabilities of this instrument; thus you will be able to get familiar with its functions step by step. As always, Barbieri electronic supports you with a one year warranty through its service organizations. Please get in touch with us in case of need.

May we also thank you for the confidence you have put in us by purchasing this instrument.

Stefan Barbieri  
Managing Director

# Barbieri Spectropad

## 1.1 WHAT YOU CAN DO WITH THIS INSTRUMENT

The Spectropad introduces a new way of accurate color control in industrial printing.

Based on the high precision Barbieri qb-technology, a technology specifically designed for industrial printing applications, this instrument features highest measuring accuracy which forms the basis to highest color quality on your printed results.

The instrument has been designed according to ISO 13655-2009.

### Quality control

With its DOC option (digital output control) you can check print quality directly on the printer with immediate feedback if printing conditions are within tolerances.

### Printer calibration and profiling

The chart measurement ability allows you to quickly measure calibration and profiling charts.

### Spot color measurement

The instrument allows measurement of single colors and indication of the respective L\*a\*b\* values and Delta E deviations against reference colors.

# Barbieri Spectropad


## 1.2 UNPACKING THE INSTRUMENT

The instrument is delivered with the following components:

1. Barbieri Spectropad
2. Rechargeable battery module
3. Power adapter/ charger
4. USB cable
5. USB stick or CD with software/ drivers
6. Quick Guide in printed format
7. Microfiber cleaning cloth

For security reasons, the rechargeable battery is separately packed with the instrument. This assures transport security by guaranteed switch-off of WiFi signals.


Before putting into operation the instrument, please insert the rechargeable battery module into its slot.




Charge the battery for 2 hours before use.

# Barbieri Spectropad


## 1.3 COMPONENTS



- 1: Measuring head
- 2: Touch display
- 3: Calibration switch
- 4: On/Off switch
- 5: USB connector
- 6: Power connector



- 7: Reference white
- 8: Position wheel




- 9: Battery holder

# Barbieri Spectropad

## 2. PUTTING INTO OPERATION

The instrument is switched on, by shortly pressing the On/Off button.

The main screen appears:



To switch off the device, select the “Switch off” button on the screen or alternatively press the On/Off switch on the instrument.

Pressing the On/Off switch for more than 5 seconds will force the instrument to switch off in case it is in a blocked condition.

### 2.1 BATTERY CHARGING

The instrument is equipped with a rechargeable battery. The battery can be charged by connecting the power adapter to the instrument.

A LED near the power connector indicates the correct charging. When instrument is switched on, the battery indicator in the status line indicates additionally if battery is charging.

Charging is finished after approx. 4 hours charge time with power adapter.

Note: The battery is charged also over the USB cable when connected, but only when instrument is switched off. Charging time is approx. 20 hours over USB cable.



# Barbieri Spectropad

## 2.2 USB CONNECTION

Before connecting the instrument to the computer, please install the Barbieri Gateway measuring software supplied on the USB stick/CD accompanying your instrument.

This will also install the required USB driver.

Then connect the instrument with your computer and launch the Barbieri Gateway software.

### Installing on a Mac computer under OS X

Switch off the Spectropad. Insert the supplied USB stick/CD-Rom into your computer, run the Gateway Installer program and follow the instructions.

Check if driver is correctly installed:

- Switch on instrument
- Open "System Information" (About this Mac/ More info...)
- Show the "System Report" and check "Hardware/ USB". The instrument "Spectropad" must be listed

# Barbieri Spectropad

## Installing on a PC with Microsoft Windows XP or later

Switch off the Spectropad. Insert the supplied USB stick/CD-Rom into your computer, run the Gateway Installer program and follow the instructions.

The USB driver is now on your computer.

- Connect the Spectropad to the computer using the supplied USB cable.
- Switch the Spectropad on.

There are two drivers to be installed for the connection between your computer and Spectropad:

1. High speed USB to serial converter
2. USB virtual serial port driver

The installation procedures are guided automatically by an installation wizard.


Note: The two installations follow automatically each other!

Your new Hardware is now installed and ready for use!

# Barbieri Spectropad

To check if the installed hardware is listed on your computer:

- Open “Control Panel”, “System”
- Select “Hardware” and click “Device Manager”.
- You will find the just installed hardware in the appearing list under “Ports” and “Universal Serial Bus controllers”.



# Barbieri Spectropad

## 2.1 PRODUCT REGISTRATION

It is recommended to register your instrument with Barbieri electronic in order to get access to privileged information like access to download area, product information/ firmware updates etc.

Registration can be done through the Barbieri Gateway measuring software or manually by registering on the Barbieri web site: [www.barbierielectronic.com](http://www.barbierielectronic.com)






# Barbieri Spectropad

## 3. USING THE INSTRUMENT

### 3.1 STATUSBAR







The upper status bar in the display indicates the following information:  
WiFi connection and signal strength

-  Sound on
-  Sound off
-  Battery status
-  Information button
-  Exit window (go back)

Some additional information on the current job is also indicated in this



**M0, M1, M2** Measuring condition (Light condition)

-  Measuring direction unidirectional from right to left
-  Measuring direction unidirectional from left to right
-  Measuring direction bi-directional
-  Spot measurement under optical aperture

### 3.2 BEGINNER-MODE



The instrument will show additional step-by-step instructions when the “beginner-mode” is enabled.



When disabled, these instructions do disappear.

It can be switched on- and off by clicking on this icon.

# Barbieri Spectropad

## 3.3 TOUCH PANEL


The instrument is equipped with a touch panel which can be operated by your fingers, or by a pointer.

Please make sure to not scratch the panel by avoiding using hard items.

The panel can be cleaned with the soft cloth included with the instrument.

Note: the color indicated on the screen are only approximate colors and no color management is applied for this screen!

## 3.4 SHOWING INSTRUMENT INFORMATION

On the main screen, click on  in the upper right of the statusbar to show the instrument information:

The following information is displayed:


- Firmware version
- Serial number (Instrument/ Modul)
- MAC address (WiFi)
- Clock
- Temperature
- relative Humidity

Note: the clock is set automatically to the computer time and date when connecting the instrument to a computer and launching a measuring software.


# Barbieri Spectropad

## 3.5 CALIBRATION

For accurate measurements, the device must be calibrated before the use.



The measuring head is equipped with a switch which allows manual insertion of the white reference.



When this switch is operated, the instrument will automatically detect this and inform you that it is being calibrated.


Release the switch when calibration is terminated.

# Barbieri Spectropad


## 3.6 MEASURING REFLECTIVE SAMPLES

The instrument can measure most reflective materials used in large format printing. The samples are placed on an even surface. For thin materials (paper, textiles) please see next chapter.

First, get familiar with the movement of the Spectropad. The instrument is equipped with two rollers and two rubbers on its lower side:



Place the instrument on a table, and put your hand on the instrument as indicated in the picture below. When pushing down your heel of the hand, the instrument is lifted up slightly and movement of the instrument in Y-direction can be done by pushing it.






# Barbieri Spectropad

Put the instrument centered on a printed chart.

Position the instrument on the center of the bottom chart line by centering the two laser beams:



When this is done, keep the instrument panel fixed, and move the measuring head to the beginning of the chart row



Now the instrument is ready to start the measurement. See chapter “Chart measuring mode” to learn how to start measurements.

Measuring speed:

A position wheel under the measuring head will recognize the current position and recognize when the end of the line has reached.

It also recognizes the speed of movement:



Make sure the speed indicator is in green range during measurement, as this will allow most exact measurements.

Note: The instrument supports Bi-directional measurements. This means, lines can be measured in direction from left to right and from right to left. For beginners it is recommended to start with uni-directional measurement.

# Barbieri Spectropad


## **3.7 MEASURE THIN REFLECTIVE SAMPLES**

When measuring thin materials (e.g. paper), the measurement must be effected on a staple of same material. This will assure accurate and repeatable measurements independent on the surface the material is placed.

Alternatively, you may place the sample to be measured on a white surface corresponding to ISO 13655-2009 white backing specifications.

# Barbieri Spectropad

## 4. CHART MEASURING MODE




The chart measuring mode is used to measure complete color charts. Predefined job definition files which have been created with the Barbieri Gateway software or 3rd party software are offered for selection and can be measured:

Select the desired job and confirm with “Select”.



Select the measuring direction to be used.




Note: the selected direction is always indicated in the Statusbar. It can be modified by clicking on the arrow icon in the Statusbar.


Note: to disable display of this message (disable Beginners-mode), click on the icon in the right lower corner.

# Barbieri Spectropad

A window will appear which shows you where to position the marker before starting measurement.



The chart measuring window will appear:



Measure the complete chart line by line as requested.

The measuring head needs to be positioned at the beginning of the line to be measured.



Stop shortly to make the instrument recognize that the start position has been found and then start moving the head over the full length of the line until the instrument tells you by a beep and by a message that measurement is terminated.




Note: Charts are measured from bottom up!

# Barbieri Spectropad

In case you stop before the end of the line, a warning will appear.





In case the measuring speed was too high, a warning will appear:



Note: A "X" symbol indicates that data is missing.

In case the wrong line is measured, an warning will appear:




When pressing "cancel" button, the measurement can be repeated. When pressing "confirm" button, data is accepted. This might be necessary if measured line is correct.

Note: A triangle symbol (stands for "delta") indicates measurements to be verified because of high Delta E color difference against the reference value.

# Barbieri Spectropad

## 5. DOC MEASURING MODE



The DOC (Digital Output Control) measuring mode allows measurement of control strips and evaluation against reference values.

The instrument supports the following control strips and their respective evaluations:

- Barbieri DOC Control strip CMYK
- FOGRA Media Wedge CMYK LFP (relative and absolute evaluation)
- IDEAlliance Digital Control strip 2009 and Control Wedge 2013

Note: This mode is only available in model Spectropad DOC. To enable DOC measuring mode, you need to order a TAN code and activate the mode through Gateway software.

If the DOC Mode is not enabled, the functionality can be tested with a Demo job.



Select one of the offered jobs in the jobs list. Jobs are defined/created in Barbieri Gateway software or 3rd party software and copied into the device.

A sample job with name "DEMO\_Printer1\_Media1" is already delivered with the device. This job uses the "Barbieri DOC strip CMYK" and comes without reference data and a predefined tolerance set. The first measurement is used as reference data.


# Barbieri Spectropad

## Measuring a reference strip

Reference values can be supplied by a reference file or by saving a measurement as reference.


In case of the sample job "DEMO\_Printer1\_Media1", you need to print out a Barbieri DOC control strip on your printer and measure this as your reference.

Measure the printed strip as described in chapter "chart measuring mode".



when chart measurement is terminated, you can save the measurement as reference with button "Save as Ref." or "Close" and discard measurement.

When choosing "Edit" button from the job list in the "Select Job" window, the actual reference file is shown.



If requested, the reference file can be deleted and this allows to measure a new strip as reference strip.

# Barbieri Spectropad

## Measuring a control strip

Measure your printed control strip by selecting the job and proceeding as described in “Chart measuring mode”.

When measurement is terminated the instrument checks the measured values against reference values and result is indicated on the display:



This page does indicate if the measured strip is within/ without the allowed tolerances.

The following parameters are evaluated:


$\Delta E_{00}$  is a color distance formula also denominated Delta E 2000

Parameter	Description
$\Delta E_{00}$ average, $\Delta E_{00}$ max.	Compare of color Gamut
$\Delta E_{00}$ prim./sec. max	Compare of ink primaries and secondaries (RGB) to indicate if ink colors have changed
$\Delta E_{00}$ grayscale avg.	Average deviation of grayscale values. Indicate linearization shift
$\Delta E_{00}$ media	Deviation of media white point. Indicates color shift on media



# Barbieri Spectropad

By pressing the “i” button, additional information is indicated:




Note: the current measurement is saved and can be transferred to the Barbieri Gateway software or 3rd party software for printout of a report.

Please see Barbieri Gateway software operating manual for more information on job parameters and job creation/ modification.

# Barbieri Spectropad

## 6. SPOT MEASURING MODE




In spot measuring mode, single colors can be measured.


Select one of the offered jobs. The job settings are defined in Barbieri Gateway software or 3rd party software.



Select the positioning marker to be used.



A window will appear which shows you where to position the marker before starting measurement.




The Spot measuring window will appear.


Position the measuring head of the instrument on a color patch by centering it with the indicator on the measuring head.

# Barbieri Spectropad

Move the measuring head so that it passes over the patch. The instrument will measure the color on the previously indicated position.




The measured color will appear on the screen.




Multiple colors can be measured and scroll buttons allow scrolling back and forward.

The measured color can be deleted by pressing 


Note: when using the “aperture” as the positioning marker, a “measure” button will be shown and when pressed, the measurement is taken immediately on the actual position of measuring head. This mode is useful when measuring on large patches or on patches where movement of measuring head is difficult.


Pressing “Delta E”  button will set the current color to the reference color and allow indication of color difference (Delta E) against this color.

Pressing “DOC”  button will set the current color to the reference color and allow indication of color difference and additionally indication if within specified tolerance.

Note: DOC mode is only available in Spectropad DOC.

# Barbieri Spectropad

Pressing “info” button  on the left upper angle of the actual color will indicate more detailed information



# Barbieri Spectropad

## 6.1 IMAGE QUALITY MODE

This mode allows to determine the homogeneity of the printer/prints using the Fogra M-Score formula.

Note: This Mode is active when "DOC Mode" is activated.

The required Light/ Medium/ Dark grey targets (supplied on USB stick/ CD with instrument) must be printed and measured by the device.

Results are shown as follows:



According to FOGRA, the resulting values are to be interpreted as follows:

M-Score	Meaning	Example
≥ 95	Perfect	Inkjetprint on proofing substrate showing no visible inhomogeneities
≥ 80	Very good	Print with slightly visible inhomogeneities (e.g. some Mottling). No visible stripes.
≥ 70	Good	Print with visible inhomogeneities (Mottling) but almost no visible stripes.
≥ 60	Satisfactory	Mottling and stripes visible. Is still accepted by most observers.
≥ 50	Adequate	Print with clearly visible mottling and/or stripes. Acceptance is highly dependent on the printed image.
< 50	Poor	Clearly visible mottling and stripes. Not accepted as high quality print

More information on M-Score: [www.fogra.org](http://www.fogra.org)

# Barbieri Spectropad

## 6.2 LINE MEASURING MODE


This mode is only activated by external software and allows measurement of a single line of color patches. A window pops up indicating an empty line.

This mode is similar to the “Chart mode”, but uses only one line. For additional instructions, see chapter “Chart measuring mode”.

# Barbieri Spectropad


## 7. SETTINGS

When pressing the “Settings” button on the touch panel of the main screen, the following windows appears:



### 7.1 WIFI INTERFACE CONFIGURATION


Select “WiFi” to enter the WiFi configuration mode:



Click on “Enable WLAN” to enable the Wlan interface (disabled by default on new instruments).

# Barbieri Spectropad

The Message “preparing Access Point” appears and the default instrument IP address is indicated as soon as ready.



The instrument supports 2 connection modes:

- SpectroPad to Wlan (Router mode)
- PC to SpectroPad (Access Point mode)

By default, the instrument is in Access Point mode which allows a PC to directly connect to the instrument by using the IP-address indicated. In this mode there is no encryption enabled.

When selecting the “SpectroPad to Wlan” mode, the instrument lists the available WLans:



Choose the desired WLAN and press “Connect”. The instrument will then try to connect to the selected WLAN. This operation might take some time.



# Barbieri Spectropad

When successfully connected, the new IP number and signal strength are shown on the screen.



For secure connections the instrument supports the WEP, WPA and WPA2 standard. If you choose a new WLAN network the passphrase must be inserted.

Please note: the instrument uses TCP/IP port 9760 to communicate over the network with your software. Make sure this port is not blocked by a firewall in your network.

## 7.2 BEGINNER MODE CONFIGURATION

Switch on and off the beginner mode message boxes.

# Barbieri Spectropad

## 8. INSTRUMENT MAINTENANCE

### 8.1 CHANGING THE REFERENCE WHITE

The instruments reference white located on the bottom of the measuring head, can be exchanged by releasing it with a screwdriver. A detailed description comes with the new reference white.

### 8.2 PACKING THE INSTRUMENT FOR TRANSPORT


For security reasons, the rechargeable lithium Ion battery must be removed before packing the instrument for shipment.

This makes sure, no fire accident can happen and the WiFi radio signals are turned off.

Remove the battery holder by unlocking the lock accessible from the bottom side of instrument.



Place battery holder in its space in original packing.



# Barbieri Spectropad

## 9. SPECIFICATIONS

### Technical data

- Measuring modes:
  - Reflectance spot color with Delta E
  - Reflectance strip scanning with automatic patch detection (linearization, profiling),
  - DOC (Digital Output Control – optional) with pass/ fail analysis
- Measurement: manual with expandable ruler for X-direction and roller guide for Y-direction
- Positioning: with laser pointers
- Measuring aperture: 6 mm diameter
- Patch size: 12x12 mm recommended
- Scanning speed: max. 200 meas./sec
- Maximum strip length: 290 mm
- Geometry: 45:0
- Physical illumination: 3 point circumferential, 7 LED-chip D50 illumination
- ISO 13655-2009 measuring mode M1 and additional M0, M2 (UVcut)
- Measuring sensor: diffraction grating with diode array
- Spectral range: 380 ... 750 nm
- Spectral resolution: 2 nm
- Optical resolution: 10 nm
- Calibration: manual with internal white reference
- Repeatability: < 0,2  $\Delta E_{00}$  on white
- Inter-instrum. agreement: 0,5  $\Delta E_{00}$  average, 1,0  $\Delta E_{00}$  max. on BCRA series II tiles
- Internal memory: 2 GByte
- Ports: USB 1.1,
- WiFi Interface: 2,4 GHz IEEE 802.11b+g, Open, WEP, WPA, WPA2 Security, FCC (USA), IC (Canada), CE (Europe), MIC (Japan), KCC (South Korea) certified
- Display: 320x240 pixel, touch screen
- Battery: Li-Ion accumulator (2 hours continuous measurement)

# Barbieri Spectropad


- Interface: USB and WiFi for Mac, PC and Linux
- Temperature sensor:  
range -20 ... +50 °C (-4 ... +122 °F)  
resolution 0,1 accuracy: +/- 1,0
- Humidity sensor:  
range 0 ... 100 %  
resolution 1 accuracy: +/- 5%
- Dimensions: 210 x 220 x 90 mm (LxWxH)
- Weight: 1,4 kg

## System requirements

- Microsoft Windows XP or later (32 and 64 bit)
- Mac OS X 10.5 or later (Intel).
- Including free measuring software Barbieri Gateway for Mac and PC

## Accessories:

- Charger: 110...240 Volt with intl adapters
- USB cable
- Cleaning tissue



**LASER RADIATION**  
**DO NOT STARE INTO BEAM**  
**CLASS II LASER**

WAVELENGTH: 630-670 nm  
MAX OUTPUT POWER: < 1mW  
Complies with 21CFR 1040.10 and 1040.11

This instrument is equipped with two class II lasers used for positioning. Do not stare into beam!

# Barbieri Spectropad

Specifications are subject to change without notice

## **EG-Konformitätserklärung**

Für das folgend bezeichnete Erzeugnis

Spectropad

wird hiermit bestätigt, daß es den wesentlichen Schutzanforderungen entspricht, die in der Richtlinie des Rates zur Angleichung der Rechtsvorschriften der Mitgliedsstaaten über die elektromagnetische Verträglichkeit (89/336/EWG) festgelegt sind.

Diese Erklärung wird verantwortlich für den Hersteller:

BARBIERI electronic OHG

I. Seidner Str. 35

I-39042 Brixen (BZ)

Italien

abgegeben durch den gesetzlichen Vertreter: Barbieri Markus.

## **Federal Communication Commission Notice**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

**CAUTION:** Operational hazard exists if AC adaptor other than original is used.

**NOTE:** Shielded interface cables must be used in order to maintain compliance with the desired FCC and European emission requirements.

# Barbieri Spectropad

For Italy:

## INFORMAZIONE AGLI UTENTI

Ai sensi dell'art. 13 del Decreto Legislativo 25 luglio 2005, n.151 "Attuazione delle Direttive 2002/95/CE, 2002/96/CE e 2003/108/CE, relative alla riduzione dell'uso di sostanze pericolose nelle apparecchiature elettriche ed elettroniche, nonché allo smaltimento dei rifiuti".

Il simbolo del cassonetto barrato riportato sull'apparecchiatura o sulla sua confezione indica che il prodotto alla fine della propria vita utile deve essere raccolto separatamente dagli altri rifiuti.

La raccolta differenziata delle presente apparecchiatura giunta a fine vita e' organizzata e gestita dal produttore. L'utente che vorrà disfarsi della presente apparecchiatura dovrà quindi contattare il produttore e seguire il sistema che questo ha adottato per consentire la raccolta separate dell'apparecchiatura giunta a fine vita.

L'adeguata raccolta differenziata per l'avvio successivo dell'apparecchiatura dimessa al riciclaggio, al trattamento e allo smaltimento ambientalmente compatibile contribuisce ad evitare possibili effetti negativi sull'ambiente e sulla salute e favorisce il reimpiego e/o riciclo dei materiali di cui è composta l'apparecchiatura. Lo smaltimento abusivo del prodotto da parte del detentore comporta l'applicazione delle sanzioni amministrative previste dalla normative vigente.



# Barbieri Spectropad

# Barbieri Spectropad

## Contact information:

BARBIERI electronic snc/OHG  
Via I.-Seidner-Str. 35  
39042 Bressanone/Brixen – Italy  
Tel. +39 0472 834024  
Fax +39 0472 833845  
[info@BARBIERlelectronic.com](mailto:info@BARBIERlelectronic.com)  
[www.BARBIERlelectronic.com](http://www.BARBIERlelectronic.com)